



2038 Second St. Norco, CA 92860
Tel: 951-808-1114 Fax:951-808-1116
dubachracing.com

YAMAHA 2010 YZ250F LOWERING KIT

1. Remove seat. (two 10mm bolts)
2. Remove shrouds. (four 8mm bolts on each side)
3. Remove both plastic radiator louvers. (no bolts)
4. Remove radiator bolts. (three 8mm bolts on each side)
5. Loosen radiator hose on top left (figure A) and bottom right (figure B) in order to slide down radiators, slide hoses up to avoid kinking. Do not cut hose, in case the lowering links are ever removed .
6. Connect three lowering links on each side of the bike using supplied flat head bolts. Make sure lowering links are matched up with the bolt holes in the radiators, (see Figure C) tighten down lowering link bolts.
7. Using original six 8mm bolts, re-install radiators to lowering links. (See Figure D & E)
8. Re-tighten all radiator hoses.
9. Re-install plastic radiator louvers.
10. Install one lowering link facing up to the top and bottom of each radiator, making sure the lowering link lines up with the shroud. (See figure F)
11. Re-install shrouds and seat using original bolts.

Figure A



Figure B



Figure C



Figure D



Figure E



Figure F

