



HONDA 09-10 CRF450R Lowering Kit

1. Remove seat. (two 10mm bolts)
2. Remove shrouds. (four 8mm bolts on each side)
3. Pull gas tank out of the way. (one 8mm bolt and strap)
4. Remove plastic radiator louvers. (no bolts)
5. Remove the radiator bolts. (two 8mm bolts on each side)
6. Loosen radiator hose on top left (See figure A) and bottom right in order to slide radiators down, slide hoses up to avoid kinking. Do not cut hose, in case the lowering links are ever removed.
7. Connect two lowering links on the left side of frame first, using supplied 14mm long flat head bolt (See figure B)
8. Repeat for right side of bike, making sure the lowering arms match up with the radiators before tightening.
9. Remove coil bolts, put in place two supplied spacers to drop down coil to necessary location. Secure coil with two 35mm long supplied bolts. (See figure C)
10. Using original 4 radiator bolts, re-install radiators to lowering links. (See figure D)
11. Connect the flat link to the wiring harness using the allen/socket bolt. The wiring harness needs to be placed between the flat link and the allen/socket bolt, the allen/socket bolt needs to screw in from the back side of the frame. The opposite side of the link will be connected to the frame. (See figure E)
12. Re-install both plastic radiator louvers .
13. Install one lowering link facing up on each radiator using supplied 20mm flat head bolt making sure lowering link lines up with shroud. (See figure F)
14. Re-install tank, shrouds, and seat using original bolts.

Figure A



Figure B



Figure C



Figure D



Figure E



Figure F



